

Welcome to Weiler Watch

Weiler Watch is a telematics system for Weiler equipment.

To access Weiler Watch and view your machines' locations, diagnostics, and fault information, one or more account administrators must first be assigned for your company.

If you are not sure whether your company already has a Weiler Watch administrator account, please check with your team or your CAT dealer. You can also contact us at weilerwatch@weilerproducts.com for help with this.

If you know your company does not have a Weiler Watch administrator account, please contact your CAT dealer to request account setup. You can also reach out to us at weilerwatch@weilerproducts.com, and we can assist you.

To link your Weiler Watch equipped machine to your Caterpillar VisionLink account, contact your Caterpillar dealer representative. This will allow you to view and manage your Weiler machine's location, diagnostics, and faults through your VisionLink account. Your Caterpillar dealer's telematics team will need to coordinate the activation.

Activating Your Account

After your account has been created for you, you will receive an activation email from Trackunit.

- Check your junk/spam folder if you do not see the email in your inbox.
- The email will be sent from no-reply@trackunit.com.
- Click the activation link in the email.
- Create and confirm your password, then save your credentials.

Once completed, you will be logged in and ready to use Weiler Watch.

For future access, sign in at: <https://new.manager.trackunit.com>


Welcome Weiler Customer

You are one step away from unlocking the full potential of Trackunit Manager.

Delve into insights about your fleet's health and usage, monitor live machine data and proactively prevent breakdowns and downtime.

Activate your account

The link is valid for 30 days





Get Started with Trackunit Manager

Enter your credentials to access your new account

Username*

A username is required

Password*

Confirm password*

Your password must be at least 12 characters long, and it must not contain any repeating characters or sequences of letters or numbers (e.g. abc, 123, aaa). Your password must not be a commonly-used password or contain your username.

Activate your account

Need help?

Adding a New User to your Customer Account

Important: You must have an **Admin** user account to invite, edit, or delete users.

Step 1: Access User Administration

1. Sign in to Trackunit Manager:
<https://new.manager.trackunit.com>
2. Select Administration from the bottom left-hand menu.
3. Navigate to the Users tab.
4. Click Invite user.

The screenshot displays the Trackunit Manager Administration interface. On the left, a dark sidebar menu contains various options, with 'Administration' highlighted at the bottom. The main content area is titled 'Administration' and features a sub-menu on the left with 'Users' selected. The 'Manage Users' section shows a table of existing users with columns for User, Username, Role, Phone, Last login, and Actions. A red arrow points from the 'Users' tab in the sub-menu to the 'Invite user' button in the top right corner of the 'Manage Users' section. Another red arrow points from the 'Actions' column of the first user row to the 'Invite user' button.

User	Username	Role	Phone	Last login	Actions
Aaron Davidson	sdvtsdf	User		3 years ago	...
Aaron Law	alwtudemo	User		2 years ago	...
Abhijeet Pandey	ext-apatudemo	Admin			...
acm fleet	acm_fleet	Fleet admin		4 days ago	...
acm_technician	acm_technician	Technician		3 days ago	...
acm_user	acm_user	User		4 days ago	...
Adam D'Cunha	adctudemo	User		2 years ago	...
Adam Petricek	apetudemo	Admin		9 months ago	...
Adam Rochford		User		Activation pending	...
Adam Zotow		User		Activation pending	...

Step 2: Enter User Information

Complete the required user information.

- **Name** and **Email** are the only mandatory fields.
- Additional information may be entered if needed.

The screenshot displays a web interface for user management. On the left is a vertical sidebar with five steps: 1. User details (highlighted), 2. Assign role, 3. Fleet visibility, 4. Additional options, and 5. Review & Confirm. The main content area is titled 'User details' and contains several input fields: 'Employee number/IPAF license', 'Company', 'Name*' (marked as mandatory), 'Email*' (marked as mandatory), and 'Phone number'. Each field has a placeholder text 'Add text...'. The 'Phone number' field contains the example value '+00 12 34 56 78'.

Step 3: Assign a User Role

Select the appropriate user role for the new user.

User details

User details overview

Assign role

Select the user's role

Fleet visibility

Grant visibility to assets

Additional options

Configure additional options

Review & Confirm

Double-check everything before saving

Fleet visibility

Grant visibility to assets by assigning groups or the entire fleet.

Full fleetNo visibilitySpecific groups

Search...

Assigning a group to a user automatically grants visibility to all assets associated with it.

☐

01 Aalborg Depot
35 assets • 11 users

☐

02 Kolding Depot
10 assets • 9 users

☐

03 Copenhagen Depot
10 assets • 6 users

☐

04 Munich Depot
10 assets • 19 users

☐

05 Frankfurt Depot
15 assets • 5 users

☐

06 Berlin Depot
92 assets • 5 users

☐

123 MRJ
6 assets • 2 users

☐

36 V Machines
8 assets • 3 users

Load more

Step 5: Additional Options / Classic Rights

Skip this as it doesn't apply to you.

✓ User details User details overview	Additional options Configure additional options
✓ Assign role Select the user's role	
✓ Fleet visibility Grant visibility to assets	
4 Additional options Configure additional options	Classic Rights This section only controls your users' legacy rights in Classic Manager. ☐ Updating rights under the module 'Settings' ☐ Updating rights under the module 'Service' ☐ Hide historical data

Step 6: Review and Send Invitation

Review the user information and click **Invite user**.

An activation email will be sent to the new user's email address.

You can confirm the invitation was sent by locating the user in the **Users** list. The **Last login** column will display: **Activation pending**.

This status will remain until the user activates their account.